



MONTEREN WIJNPAAL INDUSTRIAL

Monteer jouw nieuwe wijnrek in een paar simpele stappen:

1. Zoek een mooie plek voor de *Wijnpaal Industrial*.
2. Heb je een **stenen of betonnen muur**? Dan boor je op 163 cm hoogte een gaatje van 6 mm waarin je de plug voor steen/beton ⁽¹⁾ plaatst. Bij een **gipsenmuur** draai je de gipsplug ⁽²⁾ direct in de muur op een hoogte van 163 cm. Bij **bevestiging op hout** kun je de haakschroef ook direct in het hout ter hoogte van 163 cm draaien.
3. Draai de meegeleverde haakschroef in de plug.
4. Haak de beugel van het wijnrek over de haakschroef.

Cheers!



PLUG STEEN/BETON (1)



GIPSPLUG (2)

MANUAL WIJNPAAL INDUSTRIAL

Install your new wine rack in a few simple steps:

1. Find a nice spot for the *Wijnpaal Industrial*.
2. Do you have a **stone or concrete wall**? Then you drill a hole of 6 mm in which you place the plug for stone/concrete ⁽¹⁾ at a height of 163 cm. For a **plaster wall**, screw the plaster plug ⁽²⁾ directly into the wall at a height of 163 cm. When **fastening to wood**, you can insert the hook screw directly into the wood at a height of 163 cm.
3. Insert the supplied hook screw into the plug.
4. Hook the bracket of the wine rack over the screw.

Cheers!



PLUG STONE/CONCRETE (1)



PLASTER PLUG (2)